



B2 case

Note 3:

+ indicates collector for switches, positive for DC output sensors. For AC output sensors the + lead will be nearly in phase with current entering the sensor on the potting side.

Smith Research & Technology, Inc.



3109 N. Cascade Ave., Bldg. #201
 Colorado Springs, CO 80907-5190
 719 634 2259, FAX 719 634 2601

Inductive AC voltage and current sensors

Wednesday, September 30, 1998 at 16:19:27